

KEISER[®]

TOOLS NEEDED FOR M3i BIKE ASSEMBLY

Quantity	Description
1	Torque wrench (Minimum 45 Nm/35 ft-lb.)
1	4 inch extension
1	15 mm open-end wrench
1	16 mm, or 5/8 inch open-end wrench
1	#2 Phillips screwdriver
1	15 mm crow foot
2	10 mm wrenches
1	16 mm, or 5/8 inch crowfoot
1	5 mm Allen wrench
1	6 mm Allen wrench
1	Paste or spray wax (used to clean after assembly)
1	Clean cloth
1	LPS #3 heavy-duty rust inhibitor with straw

Questions? Contact Keiser Service at 559-256-8000

BECAUSE...
**'GOOD
ENOUGH'
ISN'T.**